



# **USER MANUAL**

## **ROSE GOLD (406)**

### **CANON QUARTZ**

**THIS WATCH INSTRUCTION MANUAL TEACH  
YOU EVERYTHING YOU NEED TO KNOW  
ABOUT YOUR CANON QUARTZ WATCH**

# INDEX

No.	Section	Page
1	Welcome & Introduction	3
2	Watch Overview	4
3	Technical Specifications	5
4	DESIGN SIGNIFICANCE	6
5	Water Resistance	7
6	Care & Maintenance	8
7	Warranty & Support	10

## THANK YOU FOR CHOOSING THE CANON QUARTZ SQUARE DIAL WATCH FOR WOMEN – SKY BLUE (MODEL CN-406)

THIS TIMEPIECE IS DESIGNED TO OFFER:

- **RELIABLE TIMEKEEPING** powered by a precise Japanese quartz movement.
- **SIGNATURE CUSHION / SQUARE CASE SHAPE** that gives a modern, premium silhouette and stands out from typical round-dial watches.
- **CALM SKY-BLUE TEXTURED DIAL** framed in radiant rose gold, designed to express serenity, clarity, and contemporary grace.
- **JEWELLERY-LIKE DIAMOND / CRYSTAL HOUR MARKERS** that add refined sparkle while keeping the dial clean and readable.
- **ROSE GOLD RADIANCE** with a polished rose-gold tone finish that elevates daily outfits and looks premium in close-ups.
- **COMFORTABLE BRACELET WATCH FEEL** with an integrated metal bracelet and a butterfly clasp for a smooth, seamless profile on wrist.
- **EVERYDAY CONFIDENCE** with 3ATM water resistance, plus a 12-month for peace of mind.

Please read this manual carefully to understand how to use, care for, and energetically align your Vastu watch for long-term enjoyment.

## WATCH OVERVIEW:



### Main Components:

- **H** - Indicates the hour
- **M** - Indicates the minutes
- **S** - Indicates running seconds
- **Crown** - Used for time setting

### How to Set a time:

1. Pull the Crown out gently until it stops (you may feel a small "click").
2. Turn the Crown until the hour and minute hands point to the correct time.
3. Push the crown back in fully to the normal position to restart the movement.

## TECHNICAL SPECIFICATIONS:



### Watch parameters:

Dial Color: Sky Blue

Dial Material: Stainless Steel

Display Type : Analog, 3-hand

Case Material : Solid brass case

Case Diameter : 35 mm (standard dress watch size)

Case Thickness : 11 mm

Bracelet Material : 306L Stainless Steel

Bracelet Width : 14 mm

Movement Type : Japanese Quartz Movement

Battery Life : 3 Years (SR626SW or equivalent)

Crystal Type : Mineral Glass (scratch-resistant)

Water Resistance : 3 ATM (30 meters)

Gender : Female

## DESIGN & AESTHETIC SIGNIFICANCE

### 1. SQUARE / CUSHION CASE – Modern geometry, signature identity

- The cushion-square case is the main identity element of this model, giving it a contemporary, premium silhouette.
- It stands out from standard round watches while still looking elegant and wearable daily.

### 2. SKY BLUE TEXTURE – Calm tone with premium depth

- The sky-blue dial uses a textured finish to create depth and soft light-play instead of a flat color.
- This makes the watch look richer in real life and in close-up photography.

### 3. ROSE GOLD FRAME – Warm contrast, feminine luxury

- Radiant rose-gold framing adds warmth and enhances the calm blue dial tone.
- This pairing works well with neutrals, denim, and office outfits, while also feeling special for occasions.

### 4. DIAMOND / CRYSTAL MARKERS – Jewellery sparkle

- Crystal-style hour markers add refined sparkle without cluttering the dial.
- This keeps readability clean while still delivering a jewellery-watch look under indoor lighting.

## **WATER RESISTANCE (3 ATM / 30M)**

Your watch is rated to 3 ATM (approximately 30 meters), meaning it can handle everyday water contact and short exposure not deep water pressure.

### **1. Suitable for**

- Everyday wear.
- Hand-washing and rain.
- Short, shallow exposure to water such as splashing and light surface swimming (non-diving, non-impact).

### **2. Not recommended for**

- Diving, snorkeling, or water sports with strong impact.
- High-pressure water (jets, power showers).
- Prolonged submersion or deep swimming sessions.
- Sauna or steam room use (heat/steam can weaken gaskets over time).

### **3. Important precautions**

- Do not operate the crown while the watch is wet or under water.
- After contact with salt water or chlorinated pool water, gently rinse with fresh water (only if exposure was light) and dry fully with a soft cloth.
- If you notice moisture/fog inside the glass, stop using the watch in water and contact a service center.

## CARE & MAINTENANCE

Taking care of your Canon Quartz watch helps it look new and work properly for a long time.

### 1. Daily Cleaning (Easy Routine)

- Wipe the watch case and glass with a soft, dry microfiber cloth to remove dust, sweat, and fingerprints.
- If your bracelet needs more cleaning, use a slightly damp cloth, then dry it fully right away.
- Do not use strong cleaners, alcohol, or chemical sprays on the watch.

### 2. Battery & Movement Care (Quartz Watches)

- Replace the battery professionally every 2-3 years (or when the watch stops).
- Professional battery replacement is important because battery leakage can damage the internal movement.
- Keep the watch away from strong magnets (phones, laptops, speakers), because magnets can cause the watch to stop or show wrong time; moving it away usually fixes it.

### **3. Case Care (Brass / Stainless Steel)**

- If your watch has a brass case: it can naturally darken over time (called patina), which is normal and happens due to air/moisture exposure.
- If you want it shiny again, gently polish only the brass area using a soft polishing cloth, and avoid the crystal and strap.
- For stainless steel, simply wipe with a dry microfiber cloth to maintain the finish.

### **6. Heat & Shock Safety**

- Avoid extreme heat (car dashboard, sauna) and extreme cold because temperature can affect components and battery life.
- Avoid drops and strong impacts because a watch has delicate internal parts and a crystal that can crack.

### **7. Long-Term Storage**

- If you won't wear the watch for a long time, store it in a cool, dry, dark place (watch box or soft pouch is best).
- Keeping it protected reduces dust buildup and scratches.

## WARRANTY & SUPPORT

If you need help with your Canon Quartz watch, you can contact our support team through the official website or WhatsApp for quick escalations.

### 1. Where to contact (Official)

- Website (Support & Contact): <https://canonquartz.com/pages/contact-us>
- Warranty claim page: <https://canonquartz.com/pages/claim-your-watch-warranty-service-support-canon-quartz>
- Support email: [canonquartzofficial@gmail.com](mailto:canonquartzofficial@gmail.com)
- WhatsApp / Phone: +91 9558579112

### 2. Warranty period (What you get)

- Your Canon Quartz watch is covered by a 1-year limited warranty from the original date of purchase.
- It covers manufacturing defects related to the watch movement, case, or dial.

### **3. What is not covered**

- The warranty does not cover the normal wear and tear, or damage due to accidents/improper use.
- Straps (leather or metal) are not included under warranty because straps naturally wear over time.

### **4. How to claim warranty (Simple steps)**

- Keep proof ready: warranty card photo (or original invoice/e-receipt if card is missing) and clear watch photos showing the issue.
- Submit the warranty claim on the official warranty page and upload the details.
- The service team replies within 2–3 business days.

### **5. Typical service timeline**

After Canon Quartz receives your watch, typical service time is 14–21 business days, then it is shipped back to you.