



# **USER MANUAL**

## **SERENITE (497)**

### **CANON QUARTZ**

**THIS WATCH INSTRUCTION MANUAL TEACH  
YOU EVERYTHING YOU NEED TO KNOW  
ABOUT YOUR CANON QUARTZ WATCH**

# INDEX

No.	Section	Page
1	Welcome & Introduction	3
2	Watch Overview	4
3	Technical Specifications	5
4	DESIGN SIGNIFICANCE	6
5	Water Resistance	7
6	Care & Maintenance	8
7	Warranty & Support	10

## THANK YOU FOR CHOOSING THE CANON QUARTZ SERENITE ROSE GOLD WHITE DIAL WOMEN'S WATCH WITH YELLOW STONE BRACELET (MODEL CN-497)

THIS TIMEPIECE IS DESIGNED TO OFFER:

- **RELIABLE TIMEKEEPING** powered by a precise Japanese quartz movement.
- **PEARL WHITE EMBOSSED DIAL ARTISTRY** featuring a luminous pearl-white face with a subtle tone-on-tone embossed pattern that looks refined, clean, and premium.
- **SIGNATURE 12 O'CLOCK ACCENT** with a single stone-like highlight near the 12 o'clock mark for a distinctive yet minimalist finish.
- **ROSE GOLD ELEGANCE** with a polished round rose-gold tone case that adds warmth and enhances the dial's glow.
- **JOYFUL YELLOW STONE JEWELLERY BRACELET** with yellow stone links set in a quatrefoil silhouette, bordered by a shimmering crystal halo for a true jewellery-watch feel.
- **DAILY-READY CONFIDENCE** with 3ATM water resistance and a 12-month warranty for peace of mind.

Please read this manual carefully to understand how to use, care for, and energetically align your Vastu watch for long-term enjoyment.

## WATCH OVERVIEW:



### Main Components:

- **H** - Indicates the hour
- **M** - Indicates the minutes
- **S** - Indicates running seconds
- **Crown** - Used for time setting

### How to Set a time:

1. Pull the Crown out gently until it stops (you may feel a small "click").
2. Turn the Crown until the hour and minute hands point to the correct time.
3. Push the crown back in fully to the normal position to restart the movement.

## TECHNICAL SPECIFICATIONS:



### Watch parameters:

Dial Color : Pearl-white dial with subtle embossed pattern

Dial Material: Stainless Steel

Display Type : Analog, 3-hand

Case Material : Stainless Steel with Premium Finish

Case Diameter : 34 mm (standard dress watch size)

Case Thickness : 12 mm

Bracelet Material : 306L Stainless Steel

Bracelet Width : 10 mm

Movement Type : Japanese Quartz Movement

Battery Life : 3 Years (SR626SW or equivalent)

Crystal Type : Mineral Glass (scratch-resistant)

Water Resistance : 3 ATM (30 meters)

Gender : Female

## DESIGN & AESTHETIC SIGNIFICANCE

### 1. PEARL WHITE DIAL – Clean glow, quiet luxury

- The pearl-white dial is designed to look luminous, crisp, and elegant without being flashy.
- Its subtle embossed pattern adds depth so the dial feels premium in real life and looks richer in close-ups.

### 2. 12 O'CLOCK ACCENT – Minimal detail, signature identity

- A single stone-like accent near 12 o'clock adds a refined highlight while keeping the dial uncluttered.
- This improves visual balance and helps you orient the dial instantly while wearing.

### 3. ROSE GOLD ROUND CASE – Warm, feminine, timeless

- The rose-gold tone round case adds warmth and softness, flattering most skin tones and outfit palettes.
- It creates a beautiful contrast against the pearl-white dial and amplifies the overall jewellery vibe.

### 4. YELLOW STONE BRACELET – Festive joy with premium sparkle

- Yellow stones set in quatrefoil links with crystal halo borders create a cheerful, celebration-ready statement.

## WATER RESISTANCE (3 ATM / 30M)

Your watch is rated to 3 ATM (approximately 30 meters), meaning it can handle everyday water contact and short exposure not deep water pressure.

### 1. Suitable for

- Everyday wear.
- Hand-washing and rain.
- Short, shallow exposure to water such as splashing and light surface swimming (non-diving, non-impact).

### 2. Not recommended for

- Diving, snorkeling, or water sports with strong impact.
- High-pressure water (jets, power showers).
- Prolonged submersion or deep swimming sessions.
- Sauna or steam room use (heat/steam can weaken gaskets over time).

### 3. Important precautions

- Do not operate the crown while the watch is wet or under water.
- After contact with salt water or chlorinated pool water, gently rinse with fresh water (only if exposure was light) and dry fully with a soft cloth.
- If you notice moisture/fog inside the glass, stop using the watch in water and contact a service center.

## CARE & MAINTENANCE

Taking care of your Canon Quartz watch helps it look new and work properly for a long time.

### 1. Daily Cleaning (Easy Routine)

- Wipe the watch case and glass with a soft, dry microfiber cloth to remove dust, sweat, and fingerprints.
- If your bracelet needs more cleaning, use a slightly damp cloth, then dry it fully right away.
- Do not use strong cleaners, alcohol, or chemical sprays on the watch.

### 2. Battery & Movement Care (Quartz Watches)

- Replace the battery professionally every 2-3 years (or when the watch stops).
- Professional battery replacement is important because battery leakage can damage the internal movement.
- Keep the watch away from strong magnets (phones, laptops, speakers), because magnets can cause the watch to stop or show wrong time; moving it away usually fixes it.

### 3. Case Care (Brass / Stainless Steel)

- If your watch has a brass case: it can naturally darken over time (called patina), which is normal and happens due to air/moisture exposure.
- If you want it shiny again, gently polish only the brass area using a soft polishing cloth, and avoid the crystal and strap.
- For stainless steel, simply wipe with a dry microfiber cloth to maintain the finish.

### 6. Heat & Shock Safety

- Avoid extreme heat (car dashboard, sauna) and extreme cold because temperature can affect components and battery life.
- Avoid drops and strong impacts because a watch has delicate internal parts and a crystal that can crack.

### 7. Long-Term Storage

- If you won't wear the watch for a long time, store it in a cool, dry, dark place (watch box or soft pouch is best).
- Keeping it protected reduces dust buildup and scratches.

## WARRANTY & SUPPORT

If you need help with your Canon Quartz watch, you can contact our support team through the official website or WhatsApp for quick escalations.

### 1. Where to contact (Official)

- Website (Support & Contact): <https://canonquartz.com/pages/contact-us>
- Warranty claim page: <https://canonquartz.com/pages/claim-your-watch-warranty-service-support-canon-quartz>
- Support email: [canonquartzofficial@gmail.com](mailto:canonquartzofficial@gmail.com)
- WhatsApp / Phone: +91 9558579112

### 2. Warranty period (What you get)

- Your Canon Quartz watch is covered by a 1-year limited warranty from the original date of purchase.
- It covers manufacturing defects related to the watch movement, case, or dial.

### **3. What is not covered**

- The warranty does not cover the normal wear and tear, or damage due to accidents/improper use.
- Straps (leather or metal) are not included under warranty because straps naturally wear over time.

### **4. How to claim warranty (Simple steps)**

- Keep proof ready: warranty card photo (or original invoice/e-receipt if card is missing) and clear watch photos showing the issue.
- Submit the warranty claim on the official warranty page and upload the details.
- The service team replies within 2–3 business days.

### **5. Typical service timeline**

After Canon Quartz receives your watch, typical service time is 14–21 business days, then it is shipped back to you.