



USER MANUAL

(DOMINION 471)

CANON QUARTZ

THIS WATCH INSTRUCTION MANUAL TEACH
YOU EVERYTHING YOU NEED TO KNOW
ABOUT YOUR CANON QUARTZ WATCH

INDEX

No.	Section	Page
1	Welcome & Introduction	3
2	Watch Overview	4
3	Get to Know Your Watch (Parts Explained)	5
4	Technical Specifications	8
5	DESIGN & AESTHETIC SIGNIFICANCE	9
6	Water Resistance	11
7	Care & Maintenance	12
8	Warranty & Support	14

THANK YOU FOR CHOOSING THE CANON QUARTZ DOMINION GREEN TEXTURED DIAL MULTI- FUNCTION WATCH (MODEL CN-471)

THIS TIMEPIECE IS DESIGNED TO OFFER:

- **RELIABLE TIMEKEEPING** powered by the Cal. VX7J Epson Japanese Quartz Movement with 3-year battery life
- **A GREEN TEXTURED DIAL WITH A SUBTLE SUNBURST TEXTURE AND THREE PRECISION SUB-DIALS AT 3, 6, AND 9 O'CLOCK.**
- **PREMIUM SILVER STAINLESS STEEL** 306L Bracelet with deployment clasp for secure, refined wear
- **COMPREHENSIVE FUNCTIONALITY** combining practical utility with sophisticated contemporary design

Please read this manual carefully to understand how to use, care for, and energetically align your Vastu watch for long-term enjoyment.

WATCH OVERVIEW:



Main Components:

- **H** – Indicates the hour
- **M** – Indicates the minutes
- **S** – Indicates running seconds
- **Crown** – Used for time setting
- **Day sub-dial** – Day of the week display
- **Date sub-dial** – Date of the month display
- **24-hour sub-dial** – AM/PM reference in 24-hour format

GET TO KNOW YOUR WATCH PARTS:



How to Set a time:

1. Pull the Crown out gently until it stops (you may feel a small "click").
2. Turn the Crown until the hour and minute hands point to the correct time.
3. Push the crown back in fully to the normal position to restart the movement.

How to Set the Day & Date:

1. Pull the Crown out gently to the first position
2. Turn the Crown slowly to advance the day and date:
 - a. Turn the Crown away from you (toward 3 o'clock) to advance the date
 - b. Turn the Crown toward you (toward 9 o'clock) to advance the day of the week
3. Push the crown back in fully when done.

GET TO KNOW YOUR WATCH PARTS:



HOW TO READ THE DAY & DATE SUBDIALS:

DAY SUB-DIAL (Right / approx. 3 o'clock)

- The day sub-dial indicates the current day of the week (MO, TU, WE, TH, FR, SA, SU).

How to adjust (manual setting):

- Use the crown calendar-setting position to move the day forward until the correct day appears.

DATE POINTER SUB-DIAL (Bottom / approx. 6 o'clock)

- The date sub-dial uses a pointer hand that indicates the date (1-31) on the printed scale.

How to adjust (manual setting):

- Use the crown calendar-setting position to move the date forward until the pointer aligns with today's date number.

GET TO KNOW YOUR WATCH PARTS:



HOW TO READ THE 24-HOUR SUBDIAL:

The 24-hour indicator at the 9 o'clock position shows whether the current time is AM or PM:

- If the subdial hand points to the upper half (1-12): The main time is in the AM (morning)
- If the subdial hand points to the lower half (13-24): The main time is in the PM (afternoon/evening)

Example: If the main hands show 2 o'clock but the 24-hour subdial points to '14', it means 2:00 PM (14:00 in 24-hour format). This syncs automatically with the main time and requires no adjustment.

TECHNICAL SPECIFICATIONS:



Watch parameters:

Dial Color : Green textured dial

Dial Material : Stainless Steel

Display Type : Analog, 3-hand + Day-Date + 24-Hour

Case Material : Stainless Steel with Premium Finish

Case Diameter : 45 mm (standard dress watch size)

Case Thickness : 15 mm

Bracelet Material : Stainless Steel 306L

Bracelet Width : 22 mm

Bezel Type : Black Tachymeter Scale Bezel

Movement Type : Cal. VX7J Epson (Japan) - Japanese Quartz Multi-Function

Battery Life : 3 Years (SR626SW or equivalent)

Crystal Type : Mineral Glass (scratch-resistant)

Water Resistance : 3 ATM (30 meters)

Gender : Male

DESIGN & AESTHETIC SIGNIFICANCE

Emerald Green Dial - The Color of Ambition

The emerald green textured dial represents sophisticated luxury, bold confidence, and aspirational success:

- The sunburst guilloch   wave texture ripples outward from the center, creating a three-dimensional effect that catches light beautifully.
- This intricate pattern is integral to the metal, not painted on, ensuring lasting beauty that will never fade or peel.
- This model is built to bridge strict formalwear and bright casual watches, offering warmth and sophistication that monochrome dials often can't deliver.

2. Multi-Function Triple Subdial - Practical Sophistication

The three integrated subdials represent comprehensive functionality without compromising aesthetics:

- Keeps you oriented through weeks of back-to-back meetings
- Prevents Monday morning confusion and weekend disorientation
- Balances the dial layout with the day window above
- Working across time zones? Know instantly if it's AM or PM
- Preventing embarrassing late-night or early-morning call mistakes
- Essential for managing project timelines and deliverables

DESIGN & AESTHETIC SIGNIFICANCE

3. Silver Stainless Steel Complement - Refined Polish

The silver bracelet perfectly complements the emerald dial:

- Luxurious Contrast - Emerald dial + silver bracelet create sophisticated elegance
- Premium Finish - Polished silver reflects premium watch design excellence
- Professional Polish - Represents refined craftsmanship and attention to detail
- Universal Versatility - Works seamlessly in any professional or formal context

4. Stainless Steel Construction - Premium Quality

The watch body represents commitment to excellence:

- Durable Materials - Stainless steel resists corrosion and wear
- Professional Finish - Premium polishing and finishing throughout
- Substantial Feel - The weight and construction convey quality and reliability
- Timeless Durability - Designed to last for many years with proper care

WATER RESISTANCE (3 ATM / 30M)

Your watch is rated to 3 ATM (approximately 30 meters), meaning it can handle everyday water contact and short exposure not deep water pressure.

1. Suitable for

- Everyday wear.
- Hand-washing and rain.
- Short, shallow exposure to water such as splashing and light surface swimming (non-diving, non-impact).

2. Not recommended for

- Diving, snorkeling, or water sports with strong impact.
- High-pressure water (jets, power showers).
- Prolonged submersion or deep swimming sessions.
- Sauna or steam room use (heat/steam can weaken gaskets over time).

3. Important precautions

- Do not operate the crown while the watch is wet or under water.
- After contact with salt water or chlorinated pool water, gently rinse with fresh water (only if exposure was light) and dry fully with a soft cloth.
- If you notice moisture/fog inside the glass, stop using the watch in water and contact a service center.

CARE & MAINTENANCE

Taking care of your Canon Quartz watch helps it look new and work properly for a long time.

1. Daily Cleaning (Easy Routine)

- Wipe the watch case and glass with a soft, dry microfiber cloth to remove dust, sweat, and fingerprints.
- If your bracelet needs more cleaning, use a slightly damp cloth, then dry it fully right away.
- Do not use strong cleaners, alcohol, or chemical sprays on the watch.

2. Battery & Movement Care (Quartz Watches)

- Replace the battery professionally every 2-3 years (or when the watch stops).
- Professional battery replacement is important because battery leakage can damage the internal movement.
- Keep the watch away from strong magnets (phones, laptops, speakers), because magnets can cause the watch to stop or show wrong time; moving it away usually fixes it.

3. Case Care (Brass / Stainless Steel)

- If your watch has a brass case: it can naturally darken over time (called patina), which is normal and happens due to air/moisture exposure.
- If you want it shiny again, gently polish only the brass area using a soft polishing cloth, and avoid the crystal and strap.
- For stainless steel, simply wipe with a dry microfiber cloth to maintain the finish.

6. Heat & Shock Safety

- Avoid extreme heat (car dashboard, sauna) and extreme cold because temperature can affect components and battery life.
- Avoid drops and strong impacts because a watch has delicate internal parts and a crystal that can crack.

7. Long-Term Storage

- If you won't wear the watch for a long time, store it in a cool, dry, dark place (watch box or soft pouch is best).
- Keeping it protected reduces dust buildup and scratches.

WARRANTY & SUPPORT

If you need help with your Canon Quartz watch, you can contact our support team through the official website or WhatsApp for quick escalations.

1. Where to contact (Official)

- Website (Support & Contact):
<https://canonquartz.com/pages/contact-us>
- Warranty claim page: <https://canonquartz.com/pages/claim-your-watch-warranty-service-support-canon-quartz>
- Support email: canonquartzofficial@gmail.com
- WhatsApp / Phone: +91 9558579112

2. Warranty period (What you get)

- Your Canon Quartz watch is covered by a 1-year limited warranty from the original date of purchase.
- It covers manufacturing defects related to the watch movement, case, or dial.

3. What is not covered

- The warranty does not cover the normal wear and tear, or damage due to accidents/improper use.
- Straps (leather or metal) are not included under warranty because straps naturally wear over time.

4. How to claim warranty (Simple steps)

- Keep proof ready: warranty card photo (or original invoice/e-receipt if card is missing) and clear watch photos showing the issue.
- Submit the warranty claim on the official warranty page and upload the details.
- The service team replies within 2-3 business days.

5. Typical service timeline

After Canon Quartz receives your watch, typical service time is 14-21 business days, then it is shipped back to you.